

HOW TO ADD ADDITIONAL PANELS TO YOUR SAN MARINO OR PLATINUM DOOR TO INCREASE WIDTH



1. Remove caps on hinge both top and bottom by removing the screws (See photo below)





2. Remove caps both top and bottom



3. Slide one side up to separate each side. See next photo.



4. Door is now ready to have panels added.



5. Get your additional door panel(s) and align channels as above.



6. Slide the door panel into place. Continue to add as many panels as required.



7. Once all panels are in place, ensure panels are aligned and reinstall caps.